

# The **BIG SPLASH**


## Set-Up & Safety Instructions



**1 800 637-3656**


**[www.twisterdisplay.com](http://www.twisterdisplay.com)**

# Parts List



**Tee Fitting**

**Quantity: 1**



**Corner Fitting**

**Quantity: 2**




**Four-Way Fitting:**

**Quantity: 2**



**36" Pipe: Quantity-4**



**Trigger Unit:**

**Quantity-1**



**44.5" Tapered Pipe: Quantity-3**




**41.5" Pipe: Quantity-5**



**Bucket Assembly:**

**Quantity-1**




**Target Cross Brace: Quantity-1**




**Collar: Quantity-1**





**Target Arm: Quantity-1**



**Filler Tube Hook:  
Quantity-1**



**Target: Quantity-1**



**Filler Tube:  
Quantity-1**



**Filler Tube  
Clips:  
Quantity-3**



**Sponge Balls:  
Quantity-12**



**Vinyl Canvas:  
Quantity-1**



Slide the bucket assembly onto the trigger unit. Make sure that it is positioned so that the roller engages with the trigger hook.



Slide on the collar and tighten.



Slide on a corner fitting and tighten.








## **Step 6**

Insert filler tube hook and tighten.

## **Step 7**

Use the clips to route the filler tube along the frame to wherever you are going to run the garden hose.





## Step 8

Attach the canvas to the frame with the Velcro straps.

## Step 9

Attach the garden hose to the connector/valve.



# **Safety Instructions**

- ◆ **Never use baseballs or hard balls. (Use only the balls provided.)**
- ◆ **Set up on level ground.**
- ◆ **Keep Big Splash staked and/or sandbagged for stability.**
- ◆ **Keep Big Splash away from electricity.**
- ◆ **Never stand under the bucket when in use.**
- ◆ **Do not allow anyone to climb on or lean against the Big Splash.**
- ◆ **Do not allow anyone to hit the target with their hand.**
- ◆ **Take down the Big Splash if there is high wind or chance of lightening.**

**1 800 637-3656**

**[www.twisterdisplay.com](http://www.twisterdisplay.com)**



# **Big Splash Replacement Parts**

**Bucket Assembly — \$38**

**Canvas — \$199**

**Collar — \$8**

**4-Way Fitting — \$12**

**Filler Tube — \$22**

**Filler Tube Clip — \$15**

**Filler Tube Hook — \$18**

**Pipe 36" — \$8**

**Pipe 41.5" — \$10**

**Pipe 44.5" (tapered) — \$12**

**Target — \$18**

**Target Arm — \$40**

**Target Cross Brace — \$38**

**Sponge Ball — \$2 (each)**

**Trigger Unit — \$60**

**1 800 637-3656**

**[www.twisterdisplay.com](http://www.twisterdisplay.com)**

# **Safety Instructions**

- ◆ **Never use baseballs or hard balls. (Use only the balls provided.)**
- ◆ **Set up on level ground.**
- ◆ **Keep Big Splash staked and/or sandbagged for stability.**
- ◆ **Keep Big Splash away from electricity.**
- ◆ **Never stand under the bucket when in use.**
- ◆ **Do not allow anyone to climb on or lean against the Big Splash.**
- ◆ **Do not allow anyone to hit the target with their hand.**
- ◆ **Take down the Big Splash if there is high wind or chance of lightening.**

**1 800 637-3656**

**[www.twisterdisplay.com](http://www.twisterdisplay.com)**